



# STRAP-ON SENSOR KIT INSTRUCTIONS

**IMAX XTRA 2**  
**80 120 160 200 240 280**  
**80P 120P 160P 200P 240P**

When replacing any part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal Heating.

For the very latest copy of literature for specification and maintenance practices visit our website [idealheating.com](http://idealheating.com) where you can download the relevant information in PDF format.



# INSTRUCTIONS

---

## CONTENTS

1.1	Introduction.....	3	1.4	Connecting the Header Sensor .....	5
1.2	Strap On Sensor Kit Parts .....	3	1.5	Connecting the Heat Circuit Flow Sensor.....	6
1.3	Connecting the Hot Water Sensor.....	4			

# INSTRUCTIONS

## 1.1 INTRODUCTION

The following document provides instructions on how to fit the strap-on sensor kit for temperature measurement of either a Hot Water Cylinder, Header or Heating Circuit.

## 1.2 STRAP ON SENSOR KIT PARTS

The kits consist of the following parts:

1. Strap-on Sensor - Shown in Fig. 1.
2. Sensors Connector Kit - Shown in Fig. 2.



Fig. 1




Fig. 2

# INSTRUCTIONS

## 1.3 CONNECTING THE HOT WATER SENSOR

Determine the position for the sensor within the Hot Water Cylinder that it needs to control. Install the sensor and secure it using the strap. Connect the DHW sensor wiring to connector I9\_CN\_A as follows. This connector is part of the Sensors connector kit:

1. Connect the DHW Sensor+ wire to pin 1 of connector I9\_CN\_A.
2. Connect the DHW Sensor- wire to pin 2 of connector I9\_CN\_A.




Fig. 3

These connections are shown Fig. 3.




Fig. 4

Insert connector I9\_CN\_A into Installer connector I9, as shown in Fig. 4.

Refer to the boiler manual for cable routing into the boiler. Secure the cables with the existing cable retention clamps or cable tie slots that are on the boiler main control panel. Ensure that isolation is maintained relative to 240V wiring. The boiler will automatically configure for outside sensor control when it is powered up again.

Configuration of the sensor to the boiler occurs during the configuration process described in the boiler manual.

# INSTRUCTIONS

## 1.4 CONNECTING THE HEADER SENSOR

The header sensor must be positioned on the secondary flow, as close to the mixing header, combined flow header or plate heat exchanger which it will need to control.

Install the sensor and secure it using the strap. Connect the Header sensor wiring to connector I9\_CN\_C as follows. This connector is part of the Sensors connector kit.

1. Connect the Header Sensor+ wire to pin 1 of connector I9\_CN\_C.
2. Connect the Header Sensor- wire to pin 2 of connector I9\_CN\_C.




Fig. 5

These connections are shown Fig. 5.




Fig. 6

Insert connector I9\_CN\_C into Installer connector I9, as shown in Fig. 6.

Refer to the boiler manual for cable routing into the boiler. Secure the cables with existing cable retention clamps or cable tie slots that are on the boiler main control panel. Ensure that isolation is maintained relative to 240V wiring. The boiler will automatically configure for the header sensor control when it is powered up again.

Configuration of the sensor to the boiler occurs during the configuration process described in the boiler manual.

# INSTRUCTIONS

## 1.5 CONNECTING THE HEAT CIRCUIT FLOW SENSOR

Please note that a Single Heating Circuit Kit (UIN 225389), or Dual Heating Circuit Kit (UIN 225390) is required for this application. Determine the position for the sensor within the heating circuit it will need to control.

Install the sensor and secure using the strap and connect the Heat Circuit Flow sensor wiring to to connector X2 as follows:

1. Connect the Heat Circuit Sensor+ wire to pin 3 of connector X2.
2. Connect the Heat Circuit Sensor- wire to pin 2 of connector X2.

These connections are shown Fig. 7.




Fig. 7

Insert connector X2 into the AGU2.550, as shown in Fig. 8.

Refer to the boiler manual for cable routing into the boiler. Secure the cables with existing cable retention clamps or cable tie slots that are on the boiler main control panel. Ensure that isolation is maintained relative to 240V wiring. The boiler will automatically configure for the header sensor control when it is powered up again.

Configuration of the sensor to the boiler occurs during the configuration process described in the boiler manual.




Fig. 8

## NOTES



**WEEE DIRECTIVE 2012/19/EC**  
**Waste Electrical and Electronic**  
**Equipment Directive**



- At the end of the product life, dispose of the packaging and product in a corresponding recycle centre.
- Do not dispose of the unit with the usual domestic refuse.
- Do not burn the product
- Remove the batteries
- Dispose of the batteries according to the local statutory requirements and not with the usual domestic refuse.



FM 59915

Manufactured under  
an ISO 9001  
registered quality  
management system

At Ideal Heating we take our environmental impact seriously, therefore when installing any Ideal Heating product please make sure to dispose of any previous appliance in an environmentally conscious manner. Households can contact their local authority to find out how. See <https://www.gov.uk/managing-your-waste-an-overview> for guidance on how to efficiently recycle your business waste.

**Technical Training**

Our Expert Academy offer a range of training options designed and delivered by our experts in heating. For details please contact:  
[expert-academy.co.uk](http://expert-academy.co.uk)

Ideal Boilers Ltd., pursues a policy of continuing improvement in the design and performance of its products. The right is therefore reserved to vary specification without notice.

Ideal is a trademark of Ideal Boilers.

Registered Office

Ideal Boilers Ltd., National Avenue, Hull, East Yorkshire, HU5 4JB

Tel 01482 492251 Fax 01482 448858

Registration No. London 322 137

Ideal Commercial Technical Helpline: 01482 498376

Ideal Parts: 01482 498665

[idealheating.com](http://idealheating.com)

**ideal**  
HEATING